

Magna-Jet Re-Calibration Procedure Instructions

If your Magna-Jet is running for few seconds then stops, you will need to recalibrate the Magna-Jet Sensor

Step 1: Remove the Jet head from the tub

Step 2: Turn on Jet Switch (make sure the color light in the tub comes on), wait for 10 seconds then press the jet Switch to turn off the Jet and color light.

Step 3: Repeat **step 2** above 6 times

Step 4: Attach the Jet head back to the tub, fill up the tub with water then turn the JET on. The Jet will run normally

Thưa Quý Khách

Nếu quý vị có Jet Nam Châm mà cứ chạy vài giây rồi tắt thì quý vị cần re-set lại bộ cảm ứng của nó

Bước 1: Lấy đầu Jet từ trong bồn ra

Bước 2: Bấm nút air button của Jet, đèn màu trong bồn sẽ sáng lên, đợi chờ đúng 10 giây đồng hồ rồi lại bấm nút air button của Jet. Lúc này đèn màu sẽ tắt.

Bước 3: Lặp lại bước thứ 2 ở trên cho đúng 6 lần

Bước 4: Đặt đầu Jet lại vào bồn và cho nước vào. Bật nút air button của JET lên, Jet Nam Châm sẽ chạy bình thường. Nếu Jet vẫn bị tắt thì đọc kỹ và lặp lại những bước trên thêm một lần nữa.

Need help? Call 1-800-483-9930 (option 2) or email support@luraco.com