

Replacing Whirlpool Pump

- 1) Move the chair forward & upright for easy access
- 2) Unplug all power cords from the pedicure foot spa
- 3) Shut off Hot & Cold water valves
- 4) Disconnect Hot & Cold braided supply lines.
- 5) Disconnect drainage pipe
- 6) Disconnect two(2) unions that are attached to the pump
- 7) Lift the spa up to remove the screws under the wooden base
- 8) Remove screws from the bottom of the wooden base
- 9) Remove air hose that is attached from the whirlpool pump
- 10) Remove whirlpool pump
- 11) Replace with new whirlpool pump, re-connect two(2) unions and air hose
- 12) Re-connect Hot&Cold water supply line & drainage pipe
- 13) Open the Hot&Cold water valve
- 14) Place the spa into its original position

